



---

11636 GOLDRING RD • ARCADIA, CALIFORNIA 91006-5815  
626-358-2559 • FAX 626-359-5701 • 800-525-6925

**Instructions for TLP-102  
Telephone Logger Patch  
P/N 39041**

The TLP-102 Telephone Logger Patch adapts most single or multiline phones, analog or digital, to a tape recorder, sound card, or other audio device. It provides a clear audio signal containing both sides of the phone conversation. The TLP-102 connects to the telephone via the modular handset connector. See the diagram and installation instructions below. Will not record speakerphone (use RRP-1).

**INSTALLATION INSTRUCTIONS**

- 1 Unplug the coil cord from the base of the phone and plug it into the modular jack on the TLP-102.
- 2 Plug the cable with the modular connector on the TLP-102 into the phone base where the coil cord was plugged.
- 3 Plug the cable with the 3.5mm plug on the TLP-102 into the tape recorder, or MIC Input of a sound card or other audio device.



11636 GOLDRING RD • ARCADIA, CALIFORNIA 91006-5815  
626-358-2559 • FAX 626-359-5701 • 800-525-6925

**Instructions for TLP-102  
Telephone Logger Patch  
P/N 39041**

