



11636 GOLDRING RD • ARCADIA, CALIFORNIA 91006-5815
626-358-2559 • FAX 626-359-5701 • 800-525-6925

Instructions Telephone Recorder Patch TRP-100 P/N 39327

The TRP-100 Telephone Recorder Patch adapts a tape recorder to single or multiple line telephones, for a clear recording of both sides of your conversations. The TRP-100 works well on all modular plug phones, including analog and digital types. The TRP-100 has an attenuated output which is required on recorders with sensitive inputs to avoid distortion.

To Install:

- 1 Disconnect the handset coil cord from the base of the telephone and replace it with the mini-mod plug from the TRP-100.
- 2 Connect the handset coil cord into the mini-mod jack on the TRP-100.
- 3 Plug the cord on the TRP-100 with the 3.5mm plug into the recorder MIC jack. The unit may be mounted at a convenient location on the base of the phone with the adhesive pad.

