The CSP-3 is a Kit Consisting of: 1 TMP-636S Telephone Patch

1 CSP CD

1 Software Registration Code



11636 GOLDRING RD • ARCADIA, CALIFORNIA 91006-5815 626-358-2559 • FAX 626-359-5701 • 800-525-6925

Installation Instructions for Call Saver[®] Pro™ CSP-3 Telephone Recording & Playback Kit For Use with Sound Cards with PC Speakers

The CSP-3 Telephone Recording & Playback Kit allows you to record from and play back to your telephone from your sound card with Call Saver Pro™ software. The TMP-636S has a built-in switch that allows you to switch sound card operation between the phone and speakers or headphones. The unit connects to the telephone via the modular handset connector as detailed below.

INSTALLATION INSTRUCTIONS

- 1 Unplug the coil cord from the base of the phone and plug it into the Handset jack on the TMP-636S.
- 2 Plug the short cable from the TMP-636S into the phone base where the coil cord was plugged.
- 3 Unplug your PC speakers from the soundcard.
 - Plug the PC speakers into the jack on the TMP-636S.
- 4 Insert the 3.5mm GREEN stereo plug into the speaker or headphone jack on the sound card.
- 5 Insert the 3.5mm PINK stereo plug into the MIC jack on the sound card.
- 6 Use the SPEAKER/PHONE Switch on the TMP-636S to switch between playing back through your PC speakers or the phone.
- 7 Insert the Call Saver Pro disk into your computer's disk drive and follow the automated instructions to install the software on your PC.

Installation Instructions for Call Saver[®] Pro™ CSP-3 Telephone Recording & Playback Kit For Use with Sound Cards with PC Speakers

