



717 SOUTH MYRTLE AVENUE • MONROVIA, CALIFORNIA 91016-3422
626-358-2559 • FAX 626-359-5701 • 800-525-6925

Instructions for TBR-10 Telephone Beep Inserter Inline, Phone Powered P/N 43850

The TBR-10 inserts a beep every 15 seconds on your phone call. The beep is heard by everyone on the call and is recorded. The unit is powered by the phone, so no separate power supply is needed.

The unit plugs in between the coil cord and the phone base, and will insert a beep on the call whenever the handset is Off-Hook.

INSTALLATION (See Diagram)

- 1 Unplug the coil cord from the base of the telephone and plug it into the modular jack on the TBR-10.
- 2 Plug the modular plug on the cord of the TBR-10 into the modular jack on the telephone base where the coil cord was plugged in.
- 3 Adjust the beep volume if necessary with the Beep Volume Pot as shown.
- 4 The unit is intended to be left free between the coil cord and the phone base. Alternately, it may be mounted with an adhesive pad to a convenient location on the phone or desk.

