

11636 GOLDRING RD • ARCADIA, CALIFORNIA 91006-5815  
 626-358-2559 • FAX 626-359-5701 • 800-525-6925


**Instructions for TBR-11, TBR-11N, & TBR-11G  
 Inline Phone Powered Telephone Beep Inserter  
 for use with CS50 & CS55 Wireless Headset Adapters**

The TBR-11 inserts a beep every 15 seconds on your phone call. The beep is heard by everyone on the call. The unit is powered by the phone, so no separate power supply is needed.

The unit plugs in between the wireless headset adapter and the phone base, and will insert a beep on the call whether the handset or headset is being used.

**INSTALLATION (See Diagram)**

- 1 Unplug the cord from the base of the telephone and plug it into the modular jack on the TBR-11.
- 2 Plug the modular plug on the cord of the TBR-11 into the modular jack on the telephone base.
- 3 Adjust the beep volume if necessary with the Beep Volume Pot as shown.
- 4 The unit may be left free between the wireless headset adapter and the phone base. Alternately, it may be mounted with an adhesive pad to a convenient location on the phone or desk.



	Quieter Beep	Different Polarity
TBR-11		
TBR-11N	✗	
TBR-11G		✗